

## SAFE WORK PRACTICE

<b>TITLE</b>	Spray Painting
<b>GENERAL</b>	Protecting workers from injuries associated with spray painting operations
<b>APPLICATION</b>	Spray painting is an integral part of construction work, which must be performed by trained workers.
<b>PROTECTIVE MECHANISMS</b>	Safe work procedure Occupational exposure limits WHMIS (MSDS) Permit system PPE ERP (Emergency Response Plan)
<b>SELECTION AND USE</b>	As per safe work procedure Provincial OH&S Legislation
<b>SUPERVISOR RESPONSIBILITY</b>	Supervisors are responsible to facilitate and/or provide proper instruction to their workers on protection requirements and training. Selection of equipment Hazard Assessment
<b>WORKER RESPONSIBILITY</b>	<ol style="list-style-type: none"> <li>1. Ensure you are fully trained.</li> <li>2. Ensure you are acquainted with safe work procedures.</li> <li>3. Follow manufacturer's recommendations.</li> <li>4. Ensure all sources of ignition are eliminated or controlled.</li> <li>5. Ensure equipment is grounded.</li> <li>6. Ensure area is ventilated.</li> <li>7. Do not smoke around spray painting operations.</li> <li>8. Ensure warning signs are in place.</li> <li>9. Practice good housekeeping.</li> <li>10. Use proper PPE when spray painting.</li> <li>11. Follow spray painting safe work procedures step by step.</li> </ol>
<p>* The information presented in this publication is intended for general use and may not apply to every circumstance. It is not a definitive guide to government regulations and does not relieve persons using this publication from their responsibilities under applicable legislation. The Northern Safety Association does not guarantee the accuracy of, nor assume liability for, the information presented here. Individual counselling and advice are available from the Association.</p>	