



## SAFE WORK PRACTICE

<b>TITLE</b>	Installation Of Blanking Devices
<b>GENERAL</b>	Protecting workers from injuries associated with the installation of blanking devices
<b>APPLICATION</b>	Blanking devices will be used to isolate Piping systems when there is or may be a danger to workers from the inadvertent release of energy or a hazardous substance into the system.
<b>PROTECTIVE MECHANISMS</b>	Safe job procedure Permit system P.P.E ERP [Emergency Response Plan]
<b>SELECTION AND USE</b>	As per job requirement
<b>SUPERVISOR RESPONSIBILITY</b>	To facilitate and/or provide proper instruction to their workers on protection requirements and training Identify locations where blinds are to be installed
<b>WORKER RESPONSIBILITY</b>	<ol style="list-style-type: none"><li>1. Isolate the system.</li><li>2. Depressurize the system.</li><li>3. Ground the system for possible static charge.</li><li>4. Disassemble piping.</li><li>5. Clean surfaces where blind/blank is to be installed.</li><li>6. Install blinds/blanks.</li><li>7. Install plugs and caps.</li><li>8. Bolt up flange and reconnect sections.</li><li>9. Re-pressurise the system and check for leaks.</li></ol>

\* The information presented in this publication is intended for general use and may not apply to every circumstance. It is not a definitive guide to government regulations and does not relieve persons using this publication from their responsibilities under applicable legislation. The Alberta Construction Safety Association does not guarantee the accuracy of, nor assume liability for, the information presented here. Individual counselling and advice are available from the Association.